

Guardian3

Tri-Band Radio Communications BDA
for First Responders

User Guide



This is an in-building DAS
Part 90 Signal Boosters , THIS IS A 90.219 CLASS B DEVICE

WARNING

This is NOT a CONSUMER device. It is designed for installation by FCC LICENSEES and QUALIFIED INSTALLERS . You MUST have an FCC LICENSE or express consent of an FCC Licensee to operate this device. You MUST register Class B signal boosters as defined in CFR 90.219. Unauthorized use may result in significant forfeiture penalties, including penalties in excess of \$100,000 for each continuing violation.

*WARNING. This is **NOT** a **CONSUMER** device. It is designed for installation by FCC **LICENSEES** and **QUALIFIED INSTALLERS**. You **MUST** have an **FCC LICENSE** or express consent of an FCC Licensee to operate this device. Unauthorized use may result in significant forfeiture penalties, including penalties in excess of \$100,000 for each continuing violation.*

This is a 90.219 Class B Device.

Under Section 90.219(d)(5) of the Commission's rules, all Part 90 Class B signal booster installations must be registered with the FCC. In February 2013, as part of the Commission's efforts to support the continued use of signal boosters in the Private Land Mobile Radio Services and Public Safety Radio Services, the Commission adopted a registration requirement for existing and future Part 90 Class B signal booster installations. The Commission found that a Class B signal booster registration system would be a valuable tool to help resolve interference should it occur.

All Part 90 licensees and signal booster operators must register existing Part 90 Class B signal boosters with the Commission by November 1, 2014. In addition, any new Class B signal booster installed after November 1, 2014 must be registered prior to operation.

Filing Registrations. To register a part 90 Class B signal booster, go to the part 90 Signal Booster Registration and Discovery page at www.fcc.gov/signal-boosters/registration and enter an FCC Registration Number (FRN) and Password in the upper right hand corner of the screen; then click on "LOGIN."

On the Signal Booster Information page, enter either (1) latitude and longitude (in decimal degrees) of the signal booster location and click on the "Get Address Info" button; or (2) the booster, city, and state, and click on the "Get Lat/Long button. The registration tool will provide a map of the booster location to verify that the location appears correct. Next, check the box(es) for the frequencies within the operating range of the signal booster and enter at least one call sign associated with the booster. In addition, enter the filer's Company Information (Company Name, Company Attention, Address, Email registration, enter Signature Information (Title, Name) and click "Submit." The system will generate a confirmation, including a booster ID number, which you may print for your records. Each booster must be submitted separately. Using the links in the upper right hand corner of the Signal Booster Confirmation page you may "Add a Booster," "View Your Boosters" or "Log out."

Accessing Registrations. Each registration will be available to the public on the same day it is filed with the Commission. Registrations may be accessed at: www.fcc.gov/signal-boosters/registration. Click on "View All Boosters" from the Part 90 Signal Booster Registration and Discovery page. The registrations can be searched and sorted by booster ID number, name of the filer, city, county, state, zip code, latitude/longitude, or call sign.

For further information please contact the FCC Licensing Support Hotline at (877) 480-3201 or submit an online help request at <https://esupport.fcc.gov/onlinerequest.htm>. Hours: Monday – Friday, 8:00– 6:00 pm.

CHAPTER 1: Introduction 1	
1.1 - Package Contents	4
1.2 - Features & Benefits	4
1.3 - Additional Items Needed	4
1.4 - How It Works	5
CHAPTER 2: Safety	5
2.1 - Safety Warnings	5-6
CHAPTER 3: Planning	7
3.1 - Overview	8
3.2 - Exterior Antenna	8
3.3 - Interior Antennas	9
3.4 - Antenna Separation	10-11
3.5 - BDA Location	12
3.6 - Accessories	12
3.7 - Need Help?	12
CHAPTER 4: Installation	13
4.1 - Selecting the Locations	13
4.2 - Soft Installation	13
4.3 - Exterior Antenna	13-14
4.4 - Internal Antennas	15
4.5 - Mounting the BDA	16
CHAPTER 5: Configuration & Testing	17
5.1 - DIP Switches and Lights	17-18
5.2 - Initial Configuration	19
5.3 - Powering on the BDA	19
5.4 - Testing	19
5.5 - Adjusting the BDA	19-20
5.6 - Automatic Shutdown	20-21
CHAPTER 6: Warranty & Specifications	21
6.1 - Warranty Information	21
6.2 - Specifications	22
6.3 - Contact Information	23

Introducing SureCall's Guardian3 Public Safety Band Amplifier. Please read this entire manual before proceeding with the installation. This manual applies to the Guardian3 model

1.1 - Package Contents

Your BDA box contains the following items:

- Guardian3 Bi-Directional Amplifier
- NEMA enclosure - Meets NEMA 4 type requirements
- Mounting kit (not shown).
- DC power supply (not shown).
- Wall anchors (not shown).

1.2 - Features & Benefits

The Guardian3 BDA offers the following features and benefits:

- Powerful in-building BDA with 31dB of adjustable gain level.
- Extends signals in areas with poor coverage due to geographical location and/or building design.
- Suitable for large areas up to approximately 80,000 square feet depending on outside signal strength.
- Power control maintains maximum output power at 3 watts EIRP.
- Automatic oscillation detection and protection system powers down the BDA to prevent harmful radio interference.

1.3 - Additional Items Needed

The Guardian3 BDA requires the following additional components for a complete installation:

- External antenna
- Lightning protector
- Cable splitter if installing multiple antennas.
- Sufficient SC-400 ultra low loss interior/exterior cable of 50 ohm.
- Multiple antennas (omnidirectional domes and/or panels by SureCall).
- Grounded surge suppressor for DC power supply.

Note: Due to the recent change of our company name from Cellphone-Mate (CM) to SureCall (SC) we have changed the prefix on all of our antennas, cables and accessories from CM to SC-.

1.4 - How It Works

The Guardian3 BDA amplifies signals from the nearest radio tower to a building and from those radios back to the tower to compensate for weak reception caused by distance, topography, building structure etc. The BDA receives the signal from an outside antenna, amplifies that signal, and then rebroadcasts it via the interior antenna(s) where it is picked up by radios. The interior antennas also pick up signals from radio devices and pass them to the BDA. The BDA amplifies these signals and passes them to the exterior antenna for rebroadcast back to the tower.

CHAPTER 2: Safety

This chapter contains important safety information designed to prevent personal injury, equipment malfunction, and/or radio interference. You are responsible for ensuring a safe installation.

2.1 - Safety Warnings

- You are responsible for knowing and following all applicable codes and regulations and for obtaining all required permits and inspections.
- Follow all safety precautions contained in this Installation Manual.
- The installation process may require working in high locations such as roofs and/or ladders. Follow applicable safety regulations and best practices to avoid falling. Take care not to drop objects off any high area. Cordon off ground areas directly below roof or ladder work when possible.
- Always use appropriate personal protective equipment such as goggles, gloves, hard hat, etc. as needed and as required.



WARNING: FAILURE TO EXERCISE CAUTION WHEN WORKING IN HIGH AREAS COULD CAUSE A FALL AND PERSONAL INJURY.

- Some components may be heavy and/or bulky. Always use proper lifting and carrying techniques when handling components, especially when working on a ladder, roof, or other area with a fall hazard.
- The exterior antenna must not be co-located or operating in conjunction with any other antenna.
- Always use a properly installed SureCall lightning protector between the exterior antenna and the BDA.



CAUTION: FAILURE TO PROPERLY INSTALL A LIGHTNING PROTECTOR CAN RESULT IN DAMAGE TO THE BDA, ANTENNAS, AND WIRING.

- Always power off the BDA before working on the roof of the building or anywhere in close proximity to the external antenna.
- Allow at least 24 inches (60cm) of separation between interior antennas and humans or animals.
- Allow at least 24 inches (60cm) of separation between exterior antennas and all persons.
- Comply with all antenna separation requirements to prevent signal oscillation.



CAUTION: SIGNAL OSCILLATION CAN CAUSE RADIO INTERFERENCE WITH RADIO TOWERS AND RESULT IN CIVIL AND/OR CRIMINAL PENALTIES.

CHAPTER 3: Planning


3.1 - Overview

The general BDA installation process follows these steps:

1. Decide where to mount the exterior antenna. This will generally be on the wall or roof of the building in the location with the strongest signal. You will need to decide whether to use an omnidirectional antenna mounted vertically or a directional Yagi antenna pointed directly at the radio tower (line of sight). You must also consider attaching a grounded lightning protector between the exterior antenna and the BDA.
2. Decide where to mount the interior antenna(s), being sure to take separation requirements into account. In general, long narrow spaces will benefit most from directional flat-panel antennas while more square spaces will benefit more from omnidirectional dome antennas.
3. Decide where to mount the BDA. This should be in a secure indoor location near a grounded power source.
4. Decide where to route the cables between the exterior antenna and the BDA and between the BDA and interior antennas.
5. Install the antennas as described in their respective Installation Manuals.
6. Route the cables to the BDA location.
7. Install the BDA as described in this manual.
8. Power on the BDA and perform the configuration and testing as described in this manual.

3.2 - Exterior Antenna

You may use either an omnidirectional antenna that covers (flat areas with no obstructions) or a directional Yagi antenna (to point directly at the tower). The omnidirectional antenna receives and transmits signals over a horizontal 360-degree circle while the Yagi antenna receives and transmits signals over a focused area and must be aimed directly (line of sight) toward the radio tower that provides the best signal to the building.




The exterior antenna and mast (if any) must be mounted in a location that meets all of the following criteria:

- Best signal strength.
- Not colocated with other antennas or used in conjunction with other antennas.
- Away from all power lines.
- 6' from lightning rod antennas.
- 24" from all persons.

These distances are general guidelines only; refer to the applicable building and electrical codes in your area to determine local requirements.


3.3 - Interior Antennas

You may use any combination of omnidirectional (dome) and/or directional (flat panel) interior antennas needed to obtain optimal signal strength throughout the building or installation area. Dome antennas provide 360-degree hemispherical coverage suitable for mostly square areas while flat panel antennas provide a focused zone of coverage suitable for long narrow areas. The following example uses two dome antennas and one panel antenna to provide full coverage (exterior Yagi antenna also shown):



Keep in mind that floor structures in multistory buildings can cause significant signal loss, which means that you may need to install interior antennas on more than one floor. Here is an example of a multistory installation:

Antenna Separation



Note: You may or may not need antennas on every floor of a multistory building depending on factors such as building material, BDA gain, etc.

3.4 - Antenna Separation

Proper antenna separation is essential in order to prevent signal oscillation (feedback) that can interfere with the radio tower. Separation is measured in a straight line from the exterior antenna to the closest interior antenna. The closest allowable distance depends on a number of factors such as BDA gain level, building material, etc. Recommended separation distances are:

Amplifier gain	Min. separation (ad)
40dB	5-6'
45dB	15-20'
50dB	50'
55dB	60'
65dB	75-80'
70dB	100'
75dB	100'-120'
80dB	120'-180'

Note: Vertical separation is more important than horizontal separation. If you are unable to obtain the required separation horizontally, try raising the exterior antenna. You may also try reducing the BDA gain as described in Chapter 5 of this manual.

You may mix and match dome and directional antennas as needed to obtain proper coverage throughout the building or area where you need to boost the signal. If you are using a Yagi exterior antenna, you should normally aim it away from all interior antennas regardless of separation to prevent oscillation.



CAUTION: SIGNAL OSCILLATION CAN CAUSE RADIO INTERFERENCE WITH RADIO TOWERS AND RESULT IN CIVIL AND/OR CRIMINAL PENALTIES.



3.6 - BDA Location

Select an indoor location for the BDA that meets the following criteria:

- Wall or ceiling mounts are acceptable.
- Near a properly grounded 110VAC outlet.
- Not in a tightly enclosed or overly hot space.
- All power and warning lights easily visible.
- Least amount of cable to connect all antennas.

3.7 - Accessories

The final step in the planning process is to make sure you have all of the necessary accessories to complete the installation. You will need all of the items listed in Chapter 1 of this manual plus some or all of the following:

- Cable clips: Use these to secure the cables to interior and exterior walls/ceilings.
- Appropriately rated sealant/caulking: Use this to waterproof the opening where the cable from the exterior antenna enters the building, if needed.
- Hand and/or power tools: As needed to complete the installation.
- Personal Equipment (PPE): Use all PPE required by local codes and/or best practices to help ensure personal safety during installation.

Note: You may need to obtain a permit from your local building department to install the BDA and antennas. Check your local building and/or electrical codes.



CAUTION: YOU ARE RESPONSIBLE FOR ENSURING THAT THE INSTALLATION MEETS ALL APPLICABLE CODES.

3.8 - Need Help?

If you need help planning your installation, please contact a qualified installer, the reseller from whom you purchased the BDA, or SureCall.

Chapter 4. Installation

This chapter describes how to install the BDA and antennas for best results.

4.1 - Selecting the Locations

Select the locations for the exterior antenna, interior antenna(s), BDA, cables, and accessories as described in the previous chapter.



CAUTION: FAILURE TO PROPERLY PLAN THE BDA INSTALLATION CAN CAUSE SIGNAL OSCILLATION AND/OR OTHER EQUIPMENT MALFUNCTION.

4.2 - Soft Installation

Perform a “soft” installation of all components to test signal coverage and oscillation before making the installation permanent. Avoid making holes or other permanent fixtures during this initial phase. Please refer to Chapter 5 of this manual for configuration and testing instructions. Proceed with the final installation once configuration and testing are complete.

4.3 - Exterior Antenna

Mount the exterior antenna in the location you selected during the planning process. Be sure to follow all of the instructions included with the antenna to ensure a safe installation. Remember:

- An omnidirectional antenna must be mounted vertically.
- A Yagi antenna must be mounted horizontally and be aimed at the desired radio tower (line of sight).



CAUTION: MOUNT THE EXTERIOR ANTENNA ON A FIXED STRUCTURE.



WARNING: FAILURE TO EXERCISE CAUTION WHEN WORKING IN HIGH AREAS COULD CAUSE A FALL AND PERSONAL INJURY.



WARNING: DO NOT TOUCH ANY LIVE ELECTRICAL WIRES OR ALLOW THE ANTENNA OR CABLING TO TOUCH ANY LIVE ELECTRICAL WIRES.



CAUTION: AVOID AIMING A YAGI ANTENNA TOWARD ANY INTERIOR ANTENNA.

1. Mount the antenna.
2. Connect a length of cable to the antenna and tighten until hand-tight.
3. Run the cable along the planned route.
4. Install a properly grounded SC-LP lightning protector.
5. Seal any holes you make in the outside of the building with appropriate caulking or sealant.

4.4 - Internal Antennas

Mount the interior antenna(s) in the location(s) you selected during the planning process. Be sure to follow the instructions included with the antenna(s) for a safe installation. Remember:

- Dome antennas should be mounted in the ceiling as close to the center of the desired coverage area as possible with the domed side pointing down.
- Flat panel antennas should be wall-mounted as close as possible to center of the wall at one end of long narrow space.



CAUTION: VERIFY THAT ALL INTERIOR ANTENNAS MEET THE SEPARATION REQUIREMENTS DESCRIBED IN THE PREVIOUS CHAPTER AND THAT NO ANTENNA IS AIMED TOWARD THE EXTERIOR ANTENNA.

1. Mount the antenna.
2. Connect a length of cable to the antenna and tighten until hand-tight.
3. If you are installing multiple antennas, run the cable to the splitter location and connect the cable to one of the outputs on the splitter.
4. Connect another length of cable to the input side of the splitter (if used) and run this cable to the BDA location.
5. It is important to keep the cable runs equal or use taps to ensure a harmonious install.



CAUTION: DO NOT CONNECT AN INTERIOR ANTENNA TO THE SPLITTER INPUT.

4.5 - Mounting the BDA

Mount the BDA as follows:

1. Verify that the selected location meets all of the criteria described in the previous chapter.
2. Attach the included mounting kit to the BDA using the screws provided. Tighten the screws by hand with a screwdriver until tight plus 1/4 to 1/2 turn. Do not over-tighten.
3. Mount 24" x 24", 3/4" thick sheet of plywood on top of sheetrock into wall studs where the BDA is to be situated. Plywood should be flush against wall. Once mounted, screw the BDA to the plywood sheet. The top side of the BDA with the lights and DIP switches should be facing away from the wall and be plainly visible standing near the BDA.
4. Connect the exterior antenna cable to the **Outside Antenna** port on the BDA.
5. Connect the interior antenna cable to the **Inside Antenna** port on the BDA.
6. Verify that all cable connections are tight and that the exterior and interior antennas are connected to the proper jacks.



CAUTION: DO NOT POWER ON THE BDA UNTIL INSTRUCTED TO DO SO.



CAUTION: NEVER POWER ON THE BDA WHEN ANY ANTENNAS ARE DISCONNECTED AS THIS COULD DAMAGE THE BDA.

CHAPTER 5: Configuration & Testing

The Guardian3 has five dipswitches. Below is an image of the dip-switches and the frequency bands they utilize for attenuation. Next to the image is a general attenuation guide.



DIP Switches

- 1) PS 700 DL dip switches control 700 band downlink
- 2) PS UL dip switches control 700 band and 800 band uplink
- 3) PS 800 DL dip switches control 800 band downlink
- 4) SMR 900 UL dip switches control 900 band uplink
- 5) SMR 900 DL dip switches control 900 band downlink

Switch 1	Switch 2	Switch 3	Switch 4	Switch 5
1dB	2dB	4dB	8dB	16dB

Switch 1 (1dB) + Switch 2 (2dB) = 3dB attenuation

Switch 1 (1dB) + Switch 2 (2dB) + Switch 3 (4dB) = 7dB attenuation

Switch 1 (1dB) + Switch 2 (2dB) + Switch 3 (4dB) + Switch 4 (8dB) = 15dB attenuation

Switch 1 (1dB) + Switch 2 (2dB) + Switch 3 (4dB) + Switch 4 (8dB) + Switch 5 (16dB) = 31dB attenuation


Configuration and Testing

Each bank of DIP switches contain five switches.

- Turning a switch OFF increases BDA gain for the selected channel.
- Turning that switch ON decreases BDA gain for the selected channel.

From left to right, the DIP switches in each bank provide 1, 2, 4, 8, and 16 dB of attenuation (reduced amplification). These switches are cumulative, meaning that the total amount of attenuation for a channel is equal to the combined dB of all ON DIP switches in the corresponding bank. For example:

- Turning all switches OFF = 0dB attenuation (BDA is at full gain).
- Turning ON Switch #1 in a bank = 1dB attenuation (BDA maximum gain is reduced by 1dB).



- Turning ON Switches #1, 3, and 5 in a bank = 1+4+16dB attenuation = 21dB attenuation.

For example, in an 80dB BDA, this means the selected channel would be reduced to 59dB (80db -21 db).


- Turning ON all switches in a bank = 1+2+4+8+16dB attenuation = 31dB attenuation

For example, in an 80 dB BDA, that means that the selected channel would be reduced to 49dB (80dB-31dB).

When the BDA is powered on:

- The green **Power** light (4) should illuminate.
- If any of the bands are oscillating, the corresponding Band lights (1,2,3) will flash red and that band will flash red and that band will shut down.

Note: When the BDA is turned on, the Band lights will flash red and yellow for approximately 10 seconds.



5.2 - Initial Configuration

By default, your BDA ships with all DIP switches turned OFF to provide maximum gain in all channels. This should always be your starting point whenever installing or reinstalling the BDA.

5.3 - Powering on the BDA

To power on the BDA:

1. Make sure that exterior and interior antenna cables are firmly connected to the proper ports on the BDA.
2. Plug a surge suppressor into a grounded 110VAC wall outlet.
3. Plug the AC end of the power adapter that came with the BDA into the surge suppressor.
4. Plug the DC end of the power adapter into the Power port on the BDA.
5. Verify that the green Power light is illuminated.



CAUTION: ONLY USE THE POWER SUPPLY INCLUDED WITH THE BDA. USE OF ANOTHER POWER SUPPLY COULD DAMAGE THE BDA AND/OR POWER SUPPLY.

5. Verify that the green Power light is illuminated.



CAUTION: DO NOT PROCEED BEYOND THIS POINT UNTIL THE BDA IS POWERED ON AND NO RED WARNING LIGHTS ARE ILLUMINATED.

5.4 – Testing

Once the BDA is powered on and no Warning lights are illuminated, walk around the entire area to test the voice and/or data signal. Refine the antenna locations and/or gain levels as needed, and then complete the permanent installation once the system is working as desired.

5.5 - Adjusting the BDA

Keep the following points in mind when adjusting the BDA:

- Full power is not always your best option. Your goal is to obtain a usable radio signal in as many areas of the building as possible. A successful installation means that you can make calls without dropping and/or have a reliable data connection.

- Do not expect to see full reception everywhere in the building as this is practically impossible.
- A good rule of thumb is that increasing gain by 6dB doubles the coverage distance of the interior antennas. Start at the lowest gain setting and increase gain gradually as needed.
- If one or more red Warning lights comes on, that indicates that there's oscillation in that band and the band will immediately shut down. If the dB gain is not adjusted, the Warning light will continue flashing. The BDA will power down and will then wake every 30 seconds for the next 15 minutes to see if the problem has been resolved. If the problem has not been resolved after 15 minutes, the BDA will shut off and will need to be unplugged and plugged back in again to reset.
- You may see oscillation in any of the bands (see Section 5.6).
- If you can't get the system to work properly, you may need to install an additional interior antenna and/or a different type of interior antenna and/or relocate interior antennas.


Note: In general, the uplink and downlink DIP switches should be set identically but this is not always the case.

5.6 - Automatic Shutdown

If equipped, the Guardian3 BDA includes an automatic shutdown feature that works in the following sequence:

1. When oscillation is detected in the uplink and/or downlink, the appropriate Warning light(s) will begin flashing red and the Power light (light 5 in the diagram on Page 18) remain green.
2. If oscillation occurs on any other band, lights 6 and/or 7, 8, 9, and 10 will blink as appropriate.
3. If the electrical current powering the BDA is too weak or too strong, lights 6 and/or 7, 8, 9, and 10 will blink yellow.
4. If the problem is not resolved, the affected side will shut down for 30 seconds.
5. The BDA will wake back up. When this occurs, the power light will be green. If oscillation resumes, the lights will flash as previously described. These 30-second cycles will continue for 15 minutes or until the problem is resolved.


For proper operation the COM pin needs to be connected to the NO pin. Do not connect the COM pin to the NC pin this will trigger the alarm.



Pin	Definition	Note
1	NO	Normal open
2	COM	Common
3	NC	Normal close
5	GND	Ground connection
9	+12V	Optional 12 VDC (250mA) auxiliary output

The alarm will be activated when following occurs:

- system shuts down due to oscillation
- system shuts down due to overload
- the current is irregular
- there is no power to the BDA



(Relay Shown in Non-Alarm Condition)

6. If the problem is not resolved within 15 minutes, the BDA will shut down (all lights off except the Power light, which is green) and must be reset by unplugging it from the power supply and plugging it back in.

To resolve oscillation, increase the antenna separation (Section 3.4) and/or the attenuation (Section 5.1).

7. Each band on the BDA works independently from other bands. Therefore, Band lights will react accordingly.

CHAPTER 6: Warranty

This chapter contains the warranty information for your SureCall product and also contains information on how to contact the company.

6.1 - Warranty Periods

Your warranty includes the following periods:

- **Three-Year Product Warranty:** SureCall products are covered under a three-year product warranty from the date of purchase. This protects the customer from any defects or problems the product may have that are solely the fault of SureCall. Incorrect installation or misuse will void this warranty. Upon the return of a defective product, SureCall will issue the customer a working replacement. All returned packages should contain all products distributed.
- **Five-Year Extended Product Warranty:** A five year warranty is available for purchase on any products sold by SureCall. A five-year warranty must be obtained at the time of purchase. This warranty adds an additional two years to the three year warranty we provide. All regulations still apply. Insert Warranty information from previous User's Guide.

6.3 - Contact Information

You may consult a SureCall customer service agent directly by contacting us as follows:

- Our online support center is at www.surecall.com/HelpDeskService.aspx If needed, you can create an online support ticket. This is the fastest and best way to get support for your product.
- Call us at (888)365-6283.

Product Name	Guardian3
Uplink Frequency Range:	788-805 / 806-824 / 896-901 (Including D Block)
Downlink Frequency Range:	758-775 / 851-869 / 935-940 (Including D Block)
Maximum Gain:	80 dB
Gain Adjustment	31 dB
Noise Figure:	≤ 8 dB
VSWR:	≤ 2.0
Supported Standards:	Public Safety 700 and 800 and SMR 900
AC Input:	110 V, 60 Hz
Maximum RF Output Power:	26dBm
P1dB:	31.5dBm
Cable:	SC-400
RF Connectors:	N Female (both ends)
Power Consumption:	90W
Operating Temperature:	-4°F to +158°F
Dimensions:	15-1/2" X 11 X 3-1/2"
Weight:	19.5 lbs.
FCC (USA):	RSNFORCE3-PSB

Three-Year Product Warranty

SureCall warrants its products for three years from the date of purchase against defects in workmanship and/or materials. Specifications are subject to change. The three-year warranty only applies to products meeting the latest FCC Certification Guidelines stated on 2/20/2013 and going into effect April 30, 2014. A two-year warranty applies to any products manufactured before May 1, 2014.

Products returned by customers must be in their original, un-modified condition, shipped in the original or protective packaging with proof-of-purchase documentation enclosed, and a Return Merchandise Authorization (RMA) number printed clearly on the outside of the shipping container.

Buyers may obtain an RMA number for warranty returns by calling the SureCall Return Department toll-free at 1-888-365-6283. Any returns received by SureCall without an RMA number clearly printed on the outside of the shipping container will be returned to sender. In order to receive full credit for signal BDAs, all accessories originally included in the signal BDA box must be returned with the signal BDA. (The Buyer does not need to include accessories sold in addition to the signal BDA, such as antennas or cables.)

This warranty does not apply to any product determined by SureCall to have been subjected to misuse, abuse, neglect, or mis-handling that alters or damages the product's physical or electronic properties.

SureCall warrants to the Buyer that each of its products, when shipped, will be free from defects in material and workmanship, and will perform in full accordance with applicable specifications. The limit of liability under this warranty is, at SureCall's option, to repair or replace any product or part thereof which was purchased up to **THREE YEARS after May 1, 2014 or TWO YEARS for products purchased before May 1, 2014**, as determined by examination by SureCall, prove defective in material and/or workmanship. Warranty returns must first be authorized in writing by SureCall. Disassembly of any SureCall product by anyone other than an authorized representative of SureCall voids this warranty in its entirety. SureCall reserves the right to make changes in any of its products without incurring any obligation to make the same changes on previously delivered products.

As a condition to the warranties provided for herein, the Buyer will prepay the shipping charges for all products returned to SureCall for repair, and SureCall will pay the return shipping with the exception of products returned from outside the United States, in which case the Buyer will pay the shipping charges.

The Buyer will pay the cost of inspecting and testing any goods returned under the warranty or otherwise, which are found to meet the applicable specifications or which are not defective or not covered by this warranty.

Products sold by SureCall shall not be considered defective or non-conforming to the Buyer's order if they satisfactorily fulfill the performance requirements that were published in the product specification literature, or in accordance with samples provided by SureCall. This warranty shall not apply to any products or parts thereof which have been subject to accident, negligence, alteration, abuse, or misuse. SureCall makes no warranty whatsoever in respect to accessories or parts not supplied by it.

Limitations of Warranty, Damages and Liability:

EXCEPT AS EXPRESSLY SET FORTH HEREIN, THERE ARE NO WARRANTIES, CONDITIONS, GUARANTEES, OR REPRESENTATIONS AS TO MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR OTHER WARRANTIES, CONDITIONS, GUARANTEES, OR REPRESENTATIONS, WHETHER EXPRESSED OR IMPLIED, IN LAW OR IN FACT, ORAL OR IN WRITING. SURECALL AGGREGATE LIABILITY IN DAMAGES OR OTHERWISE SHALL NOT EXCEED THE PAYMENT, IF ANY, RECEIVED BY CELLPHONE-MATE, INC. FOR THE UNIT OF PRODUCT OR SERVICE FURNISHED OR TO BE FURNISHED, AS THE CASE MAY BE, WHICH IS THE SUBJECT OF CLAIM OR DISPUTE. IN NO EVENT SHALL SURECALL BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES, HOWSOEVER CAUSED.

All matters regarding this warranty shall be interpreted in accordance with the laws of the State of California, and any controversy that cannot be settled directly shall be settled by arbitration in California in accordance with the rules then prevailing of the American Arbitration Association, and judgment upon the award rendered may be entered in any court having jurisdiction thereof. If one or more provisions provided herein are held to be invalid or unenforceable under applicable law, then such provision shall be ineffective and excluded to the extent of such invalidity or unenforceability without affecting in any way the remaining provisions hereof.

WARNING: E911 location information may not be provided or may be inaccurate for calls served BY USING THIS DEVICE.

48346 Milmont Drive
Fremont, California 94538
USA
888.365.6283
Fax: 510.996.7250
www.surecall.com

SureCall has made a good faith effort to ensure the accuracy of the information in this document and disclaims the implied warranties of merchantability and fitness for a particular purpose and makes no express warranties, except as may be stated in its written agreement with and for its customers. SureCall shall not be held liable to anyone for any indirect, special or consequential damages due to omissions or errors. The information and specifications in this document are subject to change without notice. © 2015. All Rights Reserved. All trademarks and registered trademarks are the property of their respective owners.

